

The Connection Diagram of GV-1 and XP 3.1

Here is the diagram of how to connect GV-1 and XP 3.1 system. User can follow the figure to complete the setup the autopilot system with a rotation speed governor. The connection between Adapter and RX is the same as before!

There is not extra setting needed in the XP3.1 system. User only needs to set the GV-1 as usual.

Attention: Strictly connect the wires as the figure below. Don't connect any other wire to RX. It is dangerous!




Figure. Connection Diagram